

Serie | 6, Free-standing dishwasher, 60 cm, White SMS6HCW01A









Optional accessories

SMZ5300 : GlassSecure Tray

Dishwasher with an Extra Clean Zone for difficult to clean dishes, and WiFi connectivity.

- VarioDrawer: Provides a convenient third loading level for cutlery and utensils.
- Extra Clean Zone: Provides an even better cleaning result foritems placed directly over the three rotating nozzles.
- ExtraQuiet program: A handy wash and dry program that is optimised for whisper quiet operation.
- HygienePlus option: Extended increased temperature cycle for hygienic cleaning.
- **Home Connect:** Control & monitor your dishwasher remotely from your smartphone or tablet.

Technical Data

Water consumption (I): 11.0 Built-in / Free-standing: Free-standing Height of removable worktop (mm): 30 845 x 600 x 600 Dimensions of the product (HxWxD): Depth with open door 90 degree (mm) : 1155 Adjustable feet: Yes - all Maximum adjustability feet (mm): 20 Net weight (kg): 53.338 Gross weight (kg): 55.5 2400 Connection Rating (W): Current (A): 10 Voltage (V): 220-240 Frequency (Hz): 50; 60 Length electrical supply cord (cm): 175 Plug type: AU plug Length inlet hose (cm): 165 Length outlet hose (cm): 190 EAN code: 4242005224937 Number of place settings: 15 0.65 Energy consumption (kWh): Total cycle time of reference programme (min): 195 Noise level (dB): 44 Installation typology: Build-under





Serie | 6, Free-standing dishwasher, 60 cm, White SMS6HCW01A

Dishwasher with an Extra Clean Zone for difficult to clean dishes, and WiFi connectivity.

Capacity

- 15 place setting capacity

Consumption rates

- 4 Star Energy rating5.5 Star WELS Water rating
- 11 litres water consumption per wash and 245 kWh energy consumption per year, based on the Eco Wash 45 °C program with a cold water connection

Design

- Stainless steel interior tub with 10 year rust through warranty
- SoftTouch buttons: Electronic soft-touch activated buttons
- Time remaining display
- Wash status display

Wash Programs and Options

- 8 Wash Programs:
- Eco Wash 45 °C
- Auto Wash 45-65 °C
- Auto Gentle 35-45 °C
- Pots/Pans 70 °C
- Quick 1h 65 °C
- Express Wash 45 °C
- ExtraQuiet 50 °C
- Favourite (Pre-Rinse is set as default)
- 4 special options:
 - Remote Start: Connect to WiFi via HomeConnect
 - Extra Dry: Provides an even better drying result by extending the drying time.
- HygienePlus: Hotter final rinse, for increased hygiene that helps to remove bacteria
- SpeedPerfect: Reduces the wash time, and can be activated at any moment (even after the wash program has started) via the SpeedPerfect button or via WiFi using the Home Connect app
- Machine Care: Maintains your dishwasher's optimum performance and hygiene.

Performance

- Extra Clean Zone: Provides an even better cleaning result for items placed directly over the three rotating nozzles in the top basket
- DosageAssist: Maximises the effectiveness of detergent tablets. The tablet is dropped into a specially engineered tray and is completely dissolved. For superior cleaning performance and a quieter wash
- EcoSilence Drive quiet and energy-efficient brushless motors (BLDC): Main Pump & Drain Pump. Variable water & spray

- pressure to achieve optimum cleaning results. Fast and extra quiet draining of water, no gargling sounds
- Aqua Sensor technology: Regulates the water usage depending on the type and degree of soiling.
 Load Sensor technology: Provides for optimal water usage even for half loads or partial loads, saving water and electricity.
- AutoBrilliance: Automatic detergent and rinse aid sensor
- Heat Exchanger: Hygienic fully enclosed drying system does not draw contaminated air (dust & allergens) from the dishwasher exterior. Reduces temperature shock, water & energy use.
- 3 stage filter system, including an innovative micro filter with a corrugated design that convenientely helps to reduce the need to wash the filter and also helps to prevent blockages.
- 5 spray levels for maximum water contact and optimum wash results
- Quiet operation: 44 dB(A)
- Extra Quiet program noise level: 42 dB(A)
- Home Connect WiFi connectivity

Flexibility

- VarioDrawer: Provides an extra loading level for cutlery and utensils
- Max Flex basket system with red coloured touchpoints, easy to identify flexing & moving parts
- Rackmatic: the top basket can be adjusted to at various height levels to maximise convenience, and even utilised on an angle which helps prevent water pooling on the top of cups
- Anti-slip protection strips in top basket
- Smooth gliding basket wheels with ball bearings in the top basket
- Smooth gliding low friction wheels in the bottom basket
- 2 foldable plate racks in top basket
- 6 foldable plate racks in bottom basket
- 2 foldable cup shelves with soft silicone edges in top basket
- 2 foldable cup shelves in bottom basket
- Time delay start: Delay program start time by 1-24 hours to suit your schedule
- Moveable cutlery basket in bottom basket
- Rack Stopper to prevent derailing of bottom basket
- Large item spray head: For washing extra large items such as baking trays and rangehood filters

Safety

- AquaStop Plus: Water supply device with lifetime anti-flood protection
- Child door lock

Appliance dimensions and weight


- Appliance dimensions (HxWxD): 84.5 cm x 60 cm x 60 cm
- Packaging dimensions (HxWxD): 89 cm x 66 cm x 68 cm
- Gross Weight: 55.5 kg
- 2 year warranty



www.bosch-home.co.nz/metapages/warranty



Serie | 6, Free-standing dishwasher, 60 cm, White SMS6HCW01A



A socket () values with extension kit